# TwinCAT3
# Download Procedure

## Created in April 2021

**DENSO**
**DENSO WAVE**

1. Beckhoff Automation user account registration is required to download this software.
   Go to https://www.beckhoff.com/ja-jp/.



Click "Register". If you already have a user account, log in and proceed to step 5.

2. Enter your information and click "Send".



Enter your information.

Click "Send" after you enter the information.

3. You will receive an automatic reply email. Click "Enable myBeckhoff".



Click "Enable myBeckhoff".

4. The Beckhoff Automation Web will open. Enter your information and log in.



Enter your email address and password. Then click "Login".

5. Access the following URL.
https://www.beckhoff.com/ja-jp/products/automation/twincat/te1xxx-twincat-3-engineering/te1000.html

**6. Click "Documentation & Downloads" under "Product information" at the bottom of the page.**



Click "Documentation & Downloads".

**7. Click "Software and tools" and then "Downloads".
From the displayed versions, click "↓ZIP" for the version you want to download.**



Click "Software and tools".

Click "Downloads".

Check the version to download and click "↓ZIP".

**8. Click "Start download" in the pop-up that appears.**



Click "Start download".

## 9. Click the name of the product you want to download.



Click the name of the product you want to download.

## 10. The download will start.



## 11. After the download is complete, unzip the Zip file and launch the software in the folder.



After decompressing the file, click "TC31-Full-Setup...".

**12. Install TwinCAT3.**



Click "Next".

**13. Accept the terms in the license agreement and proceed.**



Select "I accept the terms in the license agreement" and click "Next".

14. Select "I accept the terms in the license agreement. 3rd Party Software will be installed." and click "Next".



Select "I accept the terms in the license agreement. 3rd Party Software will be installed" and click "Next".

15. Select the setup type "Complete" and proceed.



Select "Complete" and click "Next".

16. Start the installation of TwinCAT3.
    Click "Install".



Click "Install".

17. After the installation is complete, restart your PC.



Select "Yes" to restart your PC.

18. After restarting the PC, make sure that "TwinCAT XAE Shell" is installed.
    When the startup window shown below is displayed, the download is complete.