

Product	Item	Content	Standard/Option
RC7M Controller Later Ver.3.00.0	EtherNET/IP	Mounting an EtherNet/IP Adapter board enables the controller to communicate with external devices according to the EtherNet/IP-compliant. The communication speed is 20 times as fast as DeviceNet and it enables to improve cycle time of your facilities.	Option
	CC-Link remote register	Remote resistor is capable of processing 16 consecutive I/O points as 16 bits of word data. More part numbers and information are added to CC-Link input/output Firmware of CC-Link board must be Ver. 2.4 or later.	Option
	b-CAP master/slave	Upper control devices (Master) enable to control paths of a robot (Slave) by generating free paths.	Option
Robot Tools (Image logger Ver.1.0.0)	Image logger	Save images snapped by camera (Network camera/USB camera) connected to PC. Function to record images automatically by setting the conditions using acquired external devices information as a trigger. Automatic recording can record images before the triggered point, useful for trouble shootings.	Option