

2-Jaw Electric Gripper

MPPM1606N

Italian manufacturer of grippers: Gimatic's 2-jaw electric gripper.

Features a high gripping force of 67 N in a compact body, and with plug-and-play (open/close operations using IO signals) specifications.

The light body (145 g) enables collaborative applications that makes full use of its load capacity.



Scan here
for product
information
details



Features

- Maintenance-free for up to 10 million cycles
 - Uses a long-lasting DC motor.
 - T-shaped jaws that can handle long jaws and heavy workpieces. (uses a sliding structure)
- Unique sliding screw structure
 - Energy-efficient design that does not use up current for holding after the part is gripped.
 - The jaw position is maintained to keep the workpiece from falling in the event of a power failure.
- Simple design for on/off control
 - The built-in driver enables control for opening and closing the jaws using a 24 VDC IO switch, similar to a solenoid valve.

KIT-GMP, specially developed
with DENSO specifications
(MPPM1606N built in)



Gimatic S.r.l.

Website

<http://www.gimatic.com>

Contact us

info@gimatic.com

